

WARNING

The regulator is used to charge lead and AGM accumulators of standard voltage 12V. It is designed for motorcycles, scooters, quads and water or snowmobiles according to its type.

Description

The regulator works in short-circuit and regulates the voltage.

This way of regulation is used by most Japanese and European motorcycles. It has great power at

recharging voltage 13.8VDC to 14.6VDC. It has a large thermal durability thanks to the all-aluminum construction that effectively removes it heat. You need to keep in mind the placement of the controller, preferably in places where nothing prevents good air circulation. Electronics

The controller is waterproof and resistant to rough dirt.

Technical data:

Rated voltage: 12 VDC

Rechargeable voltage: 13.8 - 14.6 VDC

Rated current: 28 ADC

Maximum current: 36 ADC

Operating temperature: -22 to +90 ° C

Installation

We recommend doing our partner service:

Brabax s.r.o.

Boleslavská 117

Luisnice 294 42

(604 204 302)

and

Moto3servis s.r.o.

Svatojánská náves 4

Tehov 251 01

(606 030 939)

And other moto service in your area.

The regulator does not allow battery-free operation! His output must be permanently connected to the battery terminals, the system is functional completely integrated in the whole. **Disconnecting the battery while in operation can lead to destruction of the regulator!**

All wires must be connected before commissioning correctly, according to the scheme from the manual from the motorcycle otherwise it is in danger destruction of the controller.

After correct installation, it is necessary to check the connector contacts a connection between the controller and the battery. Poor connection contact or the connection leads to excessive heating of the controller and threatens its destruction.

Guarantee

Before each shipment, each controller is checked and measured.

It is therefore fully functional.

Warranty for regulators is **12 months**. To recognize the warranty you need to file a tax receipt for the regulator's purchase and proof of service from the installer.

The warranty does not cover mechanical damage, defects improper installation of the controller and defects caused by a fault in electrical system of a motorcycle. **We therefore recommend installation**

entrust your proven service where they can detect cause the previous controller to be destroyed and repaired.