




RW PHONE HOLDER WITH ANTISHOCK ADAPTER USER GUIDE



For more information, details and questions visit our e-shop at:
SEFISMOTO.COM



ATTACHING THE SLEEVE



1. According to the diameter place where is a holder installed select suitable insert, place the sleeve and tighten the screw.



2. Loosen the locking nut at the back of the phone holder and push the ball of the sleeve into the socket until it clicks in. Adjust the rotation and angle of the phone holder and then tighten the locking nut.

REARVIEW MIRROR INSTALLATION



1. Loosen and remove the rearview mirror. Then insert the rearview mirror adapter and reattach and tighten the rearview mirror again.



2. Follow same step 2 as described in the previous attaching the sleeve instructions.

USE AND ADJUSTMENT

The RW phone holder is compatible with phones of sizes 5.4 - 7.2" of width 66 - 88 mm and maximum thickness up to 15 mm. Before using the holder for the first time it is necessary to adjust the width of the holder to width of your phone. Thumb screw on the left side of the holder is used to open and close the clamps of the holder, the lever on the right side is used to quickly lock the phone securely in the holder.

Adjusting the phone holder width:

1. Make sure the lever on the right side is flipped open.
2. Turn the thumb screw to open the clamps of the holder, insert your phone and tighten the thumb screw only very loosely so it is still possible to easily slide the phone in and out of the holder.
3. Flip the lever on the right side towards the holder to the closed position. The phone should get securely locked inside the holder and the lever should flip over easily without use excessive force, if the lever cannot be flipped easily, open the clamps of the holder a little more with the thumb screw and then try again.

If phone with different dimensions is used adjust the holder again.



LOOSEN TIGHTEN

Using the holder:

If adjusted correctly the phone can be easily slid in and out of the holder and then locked by flipping the lever on the right side of the holder. To release the phone only flip the lever again.

